

MODELS 724 / 732 FEATURES / INSTRUCTIONS

BULK ↗ CARTRIDGE ↗ SAUSAGE LOADERS



- ↗ Fully equipped to be used for bulk, cartridge and sausage packs with no other parts or kits needed.
- ↗ Available in capacities of 24 oz., and 32 oz.
- ↗ Built in Air Pressure Regulator
- ↗ Not to Exceed 100 lbs. PSI
- ↗ All Steel Construction
- ↗ Auto Release Shut Off Valves
- ↗ Designed to fit your existing nozzles and accessories to maximize your prior investment.

Instructions:

1. Attach regulator to handle by applying pipe dope to threaded area. Turn clockwise until fully tightened with regulator knob facing toward barrel.
2. Cut cone 1/4" to 1/8" smaller than desired bead size.
3. Attach applicator to air compressor using 7/16" fittings.
4. Set compressor at 60 to 90 PSI depending on weather and material
5. Turn regulator knob until it is fully in the "Off" Position
6. Squeeze trigger with one hand until air valve is depressed and slowly turn regulator knob to the "On" position until desired bead size is achieved.

LOADING INSTRUCTIONS

To Use as a Bulkloader:

If you are using a follow plate: Remove the front cap and wet the end of the bulk loader with water or a release agent. Also spray or put water into the gun chamber to lubricate the interior. Attach the bulk loader to the follow plate (Newborn Model FPT-05 or FPT-02), lock the thumb release and pull the load slowly until the gun is full. Newborn's neoprene follow plates use the air tight "O" ring. There is no need to screw barrel into follow plate to lock.

If you are not using a follow plate: Place the end of the bulk loader into the material about 2-3 inches and pull back the rod to bring the material into the gun. Scrape the material off of the gun to make sure the gun is clean.

To Use with Sausage Pack:

1. Pull the piston rod all the way backward.
2. Remove the front cap.
3. Insert the Floating Cup (part No. HFC-81) into the barrel. Must be evenly inserted. Push down the Floating Cup with your sausage pack (unopened) all the way to the end.
4. Cut open your sausage pack and close the front cap.
5. Slowly squeeze trigger until you feel the Floating Cup snap in the leather cup.

To Use with Cartridge:

1. Take the front cap off.
2. Loosen the bolt holding the leather cups in place.
3. Remove the leather cups.
4. Cut nozzle to preferred size using the built-in spout cutter and load cartridge into barrel.
5. Screw on front cap tightly by hand to assure proper seal.
6. Puncture seal through the plastic nozzle opening.