


Standard Drive Gun



1. Grip the handle, (do not squeeze the trigger as this will grip and lock the rod)
2. Using thumb, press in pressure release tab.
3. Pull back the rod, grabbing at ladder hook, make sure to pull evenly to avoid binding.
4. Place tip of cartridge in spout cutter, cutting at angle, depth of cut determines width of bead.
5. Use Seal Puncture tool insert into nozzle piercing the foil packaging.
6. Place Cartridge in cradle or rail.
7. Squeeze front trigger to advance the rod.
8. Press thumb pressure release and pull back rod evenly to remove cartridge.
9. If equipped, use Caulk Buddy to smooth the joint, for appearance as well as performance. In the back compartment of the Caulk Buddy are two caps to keep unused sealant fresh longer.